

# BUUGGA ISTICMAALKA

## Qasaaladda ProLine HX

### 1. Dharka geli makiinadda dhar-dhaqidda iyo xir albaabka

### 2. Saabuunta

Barnaamajka dhar-dhaqidda xaqiiji adigoo riixaayo badhanka ku qoran **OK** iyo meelaha saabuunta ku jiro ka soo muuqado shaashada.

### 3. Isticmaal xariiq-tilmaamayaasha si aad u xulato barnaamijka dhar-dhaqidda ▲ ▼

Riix badhanka ku qoran **OK** si aad u hesho barnaamijyo dhar-dhaqid kale sida barnaamajka dhaqidda ka hor

Barnaamajka dhaqidda ka hor waxaa la xulan karaa markii la riixo badhanka ku qoran **F**

Bilowga Deg-degga ah **40** **60** (Qasaaladda isla markiiba ayuu bilaabanaaya, uma baahnid inaad isticmaasho badhanka bilowga)

Barnaamajyada  
Dhar-dhaqidda

Waqtiga (daqiiqo)

Waqtiga (daqiiqo)

1.	30° Dhaqid Deg-deg ah	20	7.	90° Dhaqid Caadi	62
2.	40° Dhaqid Deg-deg ah	29	8.	25° Gacan-ku-dhaqa dogor	17
3.	60° Dhaqid Deg-deg ah	34	9.	40° Dharka isboortiga	34
4.	30° Dhaqid Caadi	35	10.	40° Goonno	24
5.	40° Dhaqid Caadi	42	11.	Dhar dogor ah	23
6.	60° Dhaqid Caadi	49	12.	Biiyo-saarid	10

### 4. Bilow **I**

### 5. Jooji/Wax-gelin deg-deg ah

Si noq-noqod ah badhanka u riix **I**

### Summadaha

- I** BILOW/WAX-GELIN DEG-DEG AH
- OK** XAQIJI BARNAAMAJKA DHAR-DHAQIDDA (Barnaamajka dhar-dhaqidda ma bilaabanaayo, xulooyin kala duwan ayaa la samayn karaa)
- ←** JOOJI (Qasaaladda wuxuu ku noqon doonaa heer-bilow)
- ▲** KOR (Loo isticmaalo kala-xulashada)
- ▼** HOOS (Loo isticmaalo kala-xulashada)
- F** SHAQAYN DHEERAAD AH (Tusaale ahaan barnaamajka dhaqidda ka hor looma isticmaali karo barnaamajka Dhaqid Deg-deg ah)
- i** MACLUUMAAD (Eeg barnaamijka dhar-dhaqidda)

**40** **60** BILOWGA DEG-DEGGA AH  
Snabbstart °C

### Meesha saabuunta lagu shubo

- I** Barnaamajka dhaqidda ka hor
- II** Barnaamajka dhar-dhaqidda caadiga ah
- III** Barnaamajka dhar-dhaqidda caadiga ah oo leh saabun dheeraad ah (warankiilo iwm)
- \*** Dhar-jilciyaha

